


Toric Split Seconds Chronograph
PF361-SLIM

PARMIGIANI
FLEURIER




Toric Split Seconds Chronograph

PF361-SLIM

3

INDICATORS

1. Hours, minutes, seconds counter
2. Chronograph seconds
3. Split-second
4. 30-minute counter
5. 12-hour counter



counterclockwise ↺ ↻ clockwise

Toric Split Seconds Chronograph

PF361-SLIM

5

WINDING

Your watch is equipped with a hand-wound mechanical movement.

It takes 72 rotations of the crown to wind your watch fully, giving you a power reserve of 65 hours.

We advise winding it fully (72 rotations) when it has stopped, then every day thereafter (22 rotations), at a set time, preferably in the morning. To do this:

1. Turn the crown clockwise.

The watch can be wound using the crown at any time.

Intensive use of the chronograph may affect the power reserve.



1 2 3



counterclockwise ↺ ↻ clockwise

Toric Split Seconds Chronograph


PF361-SLIM

7

SETTING THE TIME

1. Pull the crown out one notch.
2. Turn the crown anti-clockwise to set the hands to the desired time.
3. Push the crown back into its initial position.

Note: When the crown is pulled out, the seconds hand stops (stop seconds function).



Toric Split Seconds Chronograph

PF361-SLIM

9


SPLIT-SECONDS CHRONOGRAPH

Description of push-pieces

- A. Start/stop push-piece
- B. Split-second push-piece
- C. Reset push-piece

The two chronograph hands are started and stopped by pressing push-piece A successively. If you want to measure a split time without stopping the chronograph, press push-piece B. Only the split-second hand will stop. Pressing push-piece B a second time will enable the split-second hand to catch up to the chronograph hand without interrupting the timing. Press push-piece B again to measure a second split time.

Intensive use of the chronograph may affect the power reserve.



Toric Split Seconds Chronograph

PF361-SLIM

11

START / STOP

1. Pressing push-piece A activates the chronograph hand and the split-second hand.
2. Pressing push-piece B will stop the split-second hand.
3. Pressing push-piece B a second time will enable the split-second hand to catch up to the chronograph hand.
4. Pressing push-piece A will stop the chronograph.
5. Pressing push-piece C will reset the chronograph, split-second and counter hands.

NB: it is recommended to avoid any resets unless the split-second hand is aligned on top of the chronograph hand. Otherwise, the split-second hand will remain in its split time position. You would then need to press push-piece B to reset it.

PARMIGIANI.COM

