



Tonda GT
PF044

PARMIGIANI
FLEURIER



INDICATIONS

1. Hours, minutes, seconds counter
2. Date




counterclockwise ↺ ↻ clockwise

WINDING

Your watch automatically self-winds when you wear it. To become fully wound, it must be worn for at least 12 hours. This may vary depending on the type of user. If the watch is completely unwound, the crown will have to be turned approximately 15 times; this properly activates the mechanism. Note: the number of crown turns required to completely wind a watch varies depending on the caliber. Winding by the crown can be done at any time. When it is stopped due to an insufficient charge, it must be rewound. For this watch:

1. Turn the crown a few times clockwise to wind your watch.



Winding by the crown can be done at any time.



counterclockwise ↺ ↻ clockwise

SETTING THE TIME

1. Pull the crown out two notches.
2. Turn the crown anti-clockwise to advance the hands until the date disc (calendar) jumps (it is then midnight).
3. Turn the crown a few minutes beyond the desired time, then return to the time to be set.
4. Push the crown back to its initial position.



counterclockwise ↺ ↻ clockwise

SETTING THE DATE

1. Pull the crown out one notch.
2. Turn the crown clockwise to scroll to the desired date.
3. Push the crown back to its initial position.

Note: do not make adjustments between 10 p.m. and 1 a.m.

PARMIGIANI.COM

